



MANUAL TEDGUM



Replacement manual for anti-roll bar bushings TED11549 in Mercedes W204 (Manual #29)

Below manual shows the correct way of replacement of anti-roll bar bushings in Mercedes C Class (W204).

Due to untypical original anti-roll bushings attachment, beside of rubber elements additional metal clamps are included in the replacement kit.

- 1 Before the original bushings are replaced it is needed to mark their position on the anti-roll bar.
- 2 Remove the metal clamp and rubber from the anti-roll bar. The bar needs to be completely cleaned from remaining rubber before new bushings can be installed.



3 Stretch new clamp and put inside new rubber insert. Element needs to be stretched enough that anti-roll bar can fit inside.



4 Place the element on the anti-roll bar.



5 Tighten clamp. Fixed anti-roll bar can be installed in the car.



6 Correctly replaced element.



This and other manuals are available for download on our website at:

<https://www.tedgum.pl/en/technical-support/>

Manual shown above is just a presentation showing how the repair procedure can be made. TEDGUM® company does not bear responsibility for any errors in the manual and incorrect interpretation of the manual. Repair should be preceded by skilled personnel with the use of appropriate tools and with keeping all the safety means. All rights reserved.